User Manual





Index

CHAPTER 1: Introduction	
1 Introduction to Indoor CPE	3
2 Features & Specifications	3
3 Application Diagram	5
CHAPTER 2: Product Overview	5
1 Important Note for Using This Router	5
2 Packing List	5
3 Device Description Err	ror! Bookmark not defined.
3.1 Panel of router	5
1 Getting Started	7
1.1 Welcome to the CPE	7
1.2 Computer Configuration Requirements	7
1.3 Login the Web Management Page	7
2 Overview	9
2.1 Viewing Current Connection	9
2.2 Viewing LTE Status	9
2.3 Viewing WAN Status	
3 Status	
3.1 Statistics	
3.2 WAN Status	
3.3 LAN Status	14
4 Update	
4.1 Version Manager	
4.2 Auto upgrade	
5 Settings	
5.1 Device Information	
5.2 Network	
5.3 Ethernet	
5.4 Parental Controls	
5.5 Firewall	
5.6 VPN	
5.7 IPv6	
5.8 System	
FAQs	

CHAPTER 1: Introduction

1 Introduction to Indoor CPE

2100F12 is a highly advanced LTE indoor multi-service product solution specifically designed to meet integrated data, The product supports advanced Gigabit networking with POE power. It enables wide service coverage and provides high data throughput and networking features to customers who needs rural easy broadband access, connectivity.

2 Features & Specifications



Below is the detail info about 2100F12

	LTE CAT12
	Downlink speeds up to 560Mbps // Uplink speeds up to 30Mbps
	Carrier Aggregation; up to 4 carriers downlink
	4x4 MIMO
Basic Information	1.4MHz, 3MHz, 5MHz, 10MHz, 15MHz, 20MHz
	256QAM DL / 64QAM UL
	Maximum Transmit Power 23±2dBm (Power class 3)
	Four (4) internal directional antennas with high gain
	Maximum Peak Gain: Up to 16dBi
	Route Mode
Operational Modes	Bridge Mode / Supports remote management under bridge mode
	Static Route
	NAT static routing
	Vian in Bridge mode
	DMZ
	DNS relay, NTP and DDNS
Network Protocols and Features	IGMP proxy
	Supports DHCP server
	Support VPN (PPTP/L2TPv2/L2TPv3/GRE L2/GRE L3)/VPN Passthrough
	ICMP supported
	Port Mirror and Port Forwarding
Quality of Service Control	LTE QoS Support
duality of Service Control	Supports the DiffServ approach
	Built-in NAT Firewall
	SPI (Based on Iptables)
	Support DDOS
	Access Control (Parental Controls)
	PAddress Filtering, URL Filtering, MAC Filtering
Firewall	Firewall can be enabled or disabled via GUI
	Up to 3 level of access account
	Firmware upgrade and configuration data upload/doubload via web CUI
	FOTA Lingrade
	Local/Remote device management and firmware update via TR069 and web GI
	IPv4 only, IPv6 only, IPv4/IPv6 Dual Stack
Hardware Specifications	1 x USIM/SIM (2FF)
Physical Interface	4 LED Indicators, PWR, NET, SIM, SIG
	Dimensions: 288mm x 288 mm x 82mm
	ID Pating: ID68 Pated Enclosure
Physical Specifications	Back Enclosure Material: SurTec Treated Die Cast Alloy Enclosure
	Front Enclosure Material: Surfec Treated Die-Cast Alloy Enclosure
Operating Environment	-40°C to 60°C (-40°F to 140°F)
Contification	ECC Part 96 Authorized ECC ID: 24DX3-2100E12
Certification	PCC Part 96 Authorized, PCC ID: 2ADX3-2100F12

3 Application Diagram



CHAPTER 2: Product Overview

1 Important Note for Using This Router



 Do not remove, open or repair the case yourself. Contact with your Internet Service Provider or have it repaired at a qualified service center.
 Do not plug and unplug SIM card when device is power on.

2 Packing List

Product Images



What's in the Box?

- Horizon 2100/F12 Router
- Quick Start Guide
- Power Adapter
- Gigabit PoE Injector
 Ethernet Cable
- Cable Gland
- Pole Mounting Kit

3 Panel of router



4 LED Indicators (PWR, NET, SIM, RF Signal)

Outdoor Router		
ڻ ا	Steady on	PowerOn
POWER	Off	No Power Supply
	Steady on	Internet Available
	Off	Internet Unavailable
	Blinking (500ms interval)	Data Transmission
	Steady on	SIM ready
68 51M	Off	No SIM detected
2	Blinking (1sec interval)	SIM LOCK or PIN/PUK LOCK
	Green	Signal stronge
	Yellow	Signal good
SIGNAL	Red	Signalweek

CHAPTER 3: Software Features

1 Getting Started

1.1 Welcome to the CPE

In this document, the LTE (Long Term Evolution) CPE (customer premises equipment) will be short for CPE. Carefully read the following safety symbols to help you use your CPE safely and correctly:



1.2 Computer Configuration Requirements

For optimum performance, make sure your computer meets the following requirements.

Item	Requirement
CPU	Pentium 500 MHz or higher
Memory	128 MB RAM or higher
Hard disk	50 MB available space
Operating system	• Microsoft: Windows XP, Windows Vista, or Windows 7
	• Mac: Mac OS X 10.5 or higher
Display resolution	1024 x 768 pixels or higher
Browser	Internet Explorer 7.0 or later
	• Firefox 3.6 or later
	• Opera 10 or later
	• Safari 5 or later
	• Chrome 9 or later

1.3 Login the Web Management Page

Launch web browser to login the web management page to configure and manage the CPE.

The following procedure describes how to use a computer running Windows XP and Internet Explorer 7.0 to log in to the web management page of the CPE.

- 1. Connect the CPE properly.
- 2. Launch Internet Explorer, enter <u>http://192.168.0.1</u> in the address bar, and press Enter. As shown in Figure 1-1.





- 3. Enter the user name and password, and click Login.
- 4. You can login the web management page after the password is verified. As shown in Figure 1-2.

H orizon	
Lusername	
Password	
Login	

Figure 1-2

Щ.

The default user name and password are both **admin**. If you want to view or configure the CPE more, you should use the super account to log in to the web management page. The default super user name is **superadmin**, and the password is **admin**.

To protect your CPE from unauthorized access, change the password after your first login.

The CPE supports diagnostic function. If you encounter problems, please contact customer service for the specific using method.

To ensure your data safety, it is recommended that you turn on the firewall, and conserve your login and FTP password carefully.

1 Overview

2.1 Viewing Current Connection

To view the current connection, perform the following steps:

- 1. Choose **Overview**;
- 2. In the **Current Connection** area, view the connection status, such as DL/UL Data Rate and Online time. As shown in Figure 2-1.

Current Connection		
DL Data Rate	Current: 0 Bytes/s Max.: 2 KB/s Min.: 0 Bytes/s	
UL Data Rate	Current: 0 Bytes/s Max.: 888 Bytes/s Min.: 0 Bytes/s	
Online Time	00d 00h 01min	

Figure 2-1

2.3 Viewing LTE Status

To view the LTE network status, perform the following steps:

- 1. Choose Overview;
- 2. In the **LTE Status** area, view the information about Connect status, Mode, Cell ID, Signal quality and so on. As shown in Figure 2-3.

Settings		
Status	Connected	
Connect Method	▼ otuA	
	5	Sutimit Clincel
Status		
OL MCS	0	
UL MCS	0	
OL Frequency	2679.0 MHz	
UL Frequency	2559.0 MHz	
Bandwidth	20 MHz	
RSSI	-53 dBm	
RSRPO	-79 dBm	
RSRP1	-77 dBm	
RSRQ	-5 dB	
SINR	32 dB	
TX Druger	SK dBm	



2.4 Viewing WAN Status

To view the WAN status, perform the following steps:

- 1. Choose Overview;
- 2. In the **WAN Status** area, view the information about Connect Mode, IP, Subnet Mask, DNS Server and so on. As shown in Figure 2-4.

WAN Status	
Connect Method	LTE
Connect Mode	NAT
IP Address	172.16.15.156
Subnet Mask	255.255.255.0
DNS Server	114.114.114.114
	8.8.8.8

Figure 2-4

3 Status

3.1 Statistics

3.1.1 Viewing CPU Usage

To view the CPU usage, perform the following steps:

- 1. Choose Status;
- 2. In the **CPU Usage** area, view the CPU usage information, such as Current CPU usage, Max CPU usage, Min CPU usage. As shown in Figure 3-1.





3.1.2 Viewing Memory Usage

To view the memory usage, perform the following steps:

- 1. Choose Status;
- In the Memory Usage area, view the memory usage information, such as Total memory, Current memory usage, Max memory usage and Min memory usage. As shown in Figure 3-2.



Figure 3-2

3.1.3 Viewing APN List

To view the APN list, perform the following steps:

- 1. Choose Status;
- 2. In the APN List, view the information about APN information. As shown in Figure 3-3.
 - APN List

Profile Name	Status	IP Address	Subnet Mask
APN1	Enable	172.16.15.156	255.255.255.0
APN2	Disable		
APN3	Disable		
APN4	Disable		

Figure 3-3

3.1.4 Viewing Throughput Statistics

To view the Throughput Statistics, perform the following steps:

- 1. Choose Status;
- 2. In the **Throughput Statistics** area, view the throughput statistics, such as APN throughput and LAN throughput.
- 3. In this area, also you can choose and click the button **Reset** to empty the throughput statistics. As shown in Figure 3-4.

Throughput Statistics

Port	Recei	Received		Sent	
	Total Traffic	Packets	Total Traffic	Packets	
LAN	491KB	2289	1.33 MB	2218	
APN1	66KB	305	64KB	380	
APN2	0 Bytes	0	0 Bytes	0	
APN3	0 Bytes	0	0 Bytes	0	
APN4	0 Bytes	0	0 Bytes	0	

Figure 3-4

3.2 WAN Status

3.2.1 WAN Status

To view the WAN status, perform the following steps:

1.Choose Status;

2.Choose WAN Status

3.In the **WAN Status** area, view the **WAN Status** such as IP Address, Primary DNS and Secondary DNS. As shown in Figure 3-5.

WAN Status

WAN Status	
IP Address	10.35.226.121
Primary DNS	211.136.150.86
Secondary DNS	211.136.150.88

Figure 3-5

3.2.2 Connection Status

To view the connection status, perform the following steps:

1.Choose Status;

2.Choose WAN Status

2.In the Connection Status area, view the Connection Status such as Connection mode,Connection Status, USIM Status, IMEI, IMSI, RSRP0, RSRP1, RSRQ, RSSI, SINR, E-cell ID,EnodeB ID and Cell ID. As shown in Figure 3-6.

Connection Status

Connection mode	LTE
Connection Status	No Service
USIM Status	Ready
IMEI	862165040901371
IMSI	460680058800102
RSRP0	0 dBm
RSRP1	0 dBm
RSRQ	0 dB
RSSI	0 dBm
SINR	0 dB
E-cell ID	
EnodeB ID	
Cell ID	

Figure 3-6

3.3 LAN Status

3.3.1 LAN Status

To view the WAN status, perform the following steps:

1.Choose Status;

2.Choose LAN Status

3. In the LAN Status area, view the LAN Status such as LAN IP and DHCP Server. As shown in Figure 3-7.

LAN Status

LAN Status	
LAN IP	192.168.1.1
DHCP Server	192.168.1.100-192.168.1.249

Figure 3-7

3.3.2 Device List

To view the device list, perform the following steps:

- 1. Choose Status;
- 2. Choose LAN Status;
- 3. In the **Device List** area, view the device information which connect to the CPE, such as Device name, Mac address, IP address and Lease time. As shown in Figure 3-8.

Device List						
Index	Device Name	MAC Address	IP Address	Lease Time	Туре	
1	LAPTOP-4MDEGLLJ	B4 A9 FC EB 80 4F	192.168.1.219	00d 11h 31min	LAN DHCP	

Figure 3-8

4 Update

4.1 Version Manager

This function enables you to upgrade the software version of the CPE to a new version.

Viewing Version Info

To view the version info, perform the following steps:

- 1. Choose **Update>Version Manager**.
- 2. In the **Version Info** area, you can view the product name and software version. As shown in Figure 4-1.

Overview Status I	Jpdate Settings
😚 Version Manager	
Auto Upgrade	Version Manager
	Tip: It is forbidden to power off during the upgrade process.
	Version Information
	Product Model
	Running software version
	Local Upgrade
	Version File Choose File No file chosen
	Upgrade
	Figure 4-1

4.1.1 Version Upgrade

To perform an upgrade successfully, connect the CPE to your computer through a network cable, save the upgrade file on the computer, and make sure the CPE is not connected to anything other than a power adapter and the computer.

To perform an upgrade, perform the following steps:

- 1. Choose Update>Version Manager.
- 2. In the **Version Upgrade** area, click **Browser**. In the displayed dialog box, select the target software version file.
- 3. Click **Open**. The dialog box choses. The save path and name of the target software version file are displayed in the Update file field.
- 4. Click Submit.

5. The software upgrade starts. After the upgrade, the CPE automatically restarts and runs the new software version. As shown in Figure 4-2.



During an upgrade, do not power off the CPE or disconnect it from the computer.

Local Upgrade			
Version File	Choose File No file chosen		
Upgrade			
Figure 4-2			

4.2 Auto upgrade

To perform a ftp auto upgrade successfully, make sure the CPE is connected to the Internet.

To perform a ftp auto upgrade, perform the following steps:

- 1. Choose Update>Auto upgrade.
- 2. Enable auto upgrade.
- 3. If you want to check new firmware after connect to Internet, you need to enable the item of **Check new firmware after connect to Internet**.
- 4. Set the ftp server address to the **Upgrade folder** box.
- 5. Set Version file. //This contain the new FW name
- 6. Set User name and Password.
- 7. Set the Interval of checking new firmware. //Check upgrade periodic
- 8. Set Start time. // The time of upgrade begin
- 9. Set Random time. // Out of this time, UE will not upgrade.
- 10. Click **Submit**. As shown in Figure 4-3.
 - 1,The CPE will automatically upgrade according to the setting. During an upgrade,
 do not disconnect the power supply or operate the CPE.

2, If set interval of checking new FW, the start time and random time will shouldn't be set.

2100F12 User Manual

Overview Status U	Ipdate Settings	
🕀 Version Manager		
🕀 Auto Upgrade	Auto Upgrade	
	Settings	
	Auto Upgrade	Enable
	Check New FW after connected	Enable
	Upgrade Folder	[ftp ▼]:// *
	Version File	version.txt *
	Username	admin *
	Password	*
	Check New FW Every	✓ 24
	Start Time(24hrs)	0 •
	Random Time	3 •
	Figure 4-3	

5 Settings

5.1 Device Information

To view the System Information, perform the following steps:

- 1. Choose Settings;
- 2. In the **System Information** area, view the system status, such as Running time. As shown in Figure 5-1.

System Information

Running Time

00d 00h 14min

Figure 5-1

5.1.1 Viewing the Version Information

To view the Version Information, perform the following steps:

- 1. Choose Settings;
- In the Device Information area, view the device information, such as Product name, Product Model, Hardware Version, Software version, UBoot version and CPE SN. As shown in Figure 5-2.

Device Information

System Information				
Running Time	00d 00h 16min			
Version Information				
Product Model				
Hardware Version				
Software Version				
UBOOT Version	V1.0.2			
Serial Number	RP410201200000004			
IMEI	862165040656108			
IMSI	460680058800030			



5.1.2 Viewing LAN Status

To view the LAN status, perform the following steps:

- 1. Choose Settings;
- 2. In the LAN Status area, view the LAN status, such as Mac address, IP address and Subnet mask. As shown in Figure 5-3.

LAN Status

MAC Address	A8:93:52:0A:12:90
IP Address	192.168.0.1
Subnet Mask	255.255.255.0

Figure 5-3

5.2 Network

5.2.1 WAN Settings

- 1. To set the network mode, perform the following steps:
- 2. Choose Network >WAN Settings;
- 3. In the Network Mode area, select a mode between NAT and ROUTER and Bridge
- 4. Click **Submit**. As shown in Figure 5-4.

WAN Settings

NAT	•
NAT BRIDGE ROUTER	
	NAT NAT BRIDGE ROUTER

5.2.2 DNS

To set the DNS settings, perform the following steps:

1.Choose Network >DNS Settings;

2.In the Settings area, you can set the Primary DNS and Secondary DNS. As shown in Figure 5-5.

2100F12 User Manual

DN	DNS Settings				
	Static DNS has the highest pric	ority, VPN DNS follows it and LTE DNS has the lowest priority. If you want to restore the VPN/LTE DNS, please clear the two DNS configuration and submit.			
	Settings				
	Primary DNS	114.114.114			
	Secondary DNS	8.8.8.8			



5.2.3 LTE Settings

To set the LTE network, perform the following steps:

1.Choose Network >LTE Settings;

2.In the Settings area, you can set the configuration of LTE network;

3.In the **Status** area, you can view the LTE network connect status, such as Frequency, RSSI, RSRP, RSRQ, CINR, SINR, Cell ID and so on. As shown in Figure 5-6.

(j)Device Information		
🚠 Network	LTE Settings	
WAN Settings		
LTE Settings	Settings	
Scan Mode	Ctatua	Connected
APN Management	Status	Connected
PIN Management	Connect Method	Auto 🔻
Dual SIM		
SIM Lock		
LAN Settings		
DMZ Settings	Status	
Static Route	DL MCS	25
Ethernet	UL MCS	0
∕≂ Wi-Fi	DL Frequency	3560.0 MHz
💭 Firewall		3560.0 MHz
K VPN	Bandwidth	
et leve	Danuwidin	
	RSSI	-72 dBm
System	RSRP0	-98 dBm
	RSRP1	-127 dBm
	RSRQ	-5 dB

Figure 5-6

5.6.2.1 5.2.3.1 Connect Method Setting

To set the connect method, perform the following steps:

1. Choose Network > LTE Settings;

2. In the **Setting** area, Select a connect method between **Auto** and **Manual**. As shown in Figure 5-7.

Settings			
Settings			
Status	Connected		
Connect Method	Auto		

Figure 5-7

5.6.2.2 5.2.3.2 Auto Connect LTE Network

To set the CPE automatically connect to the internet, perform the following steps:

- 1. Choose Network > LTE Settings;
- 2. In the **Setting** area, set the connect method as **Auto**. When the LTE network is ready, the CPE will be connected automaticity. As shown in Figure 5-8.

LTE Settings

Settings	
Status	Connected
Connect Method	Auto 🔻

Status

DL MCS	28
UL MCS	2
DL Frequency	3560.0 MHz
UL Frequency	3560.0 MHz
Bandwidth	20 MHz
RSSI	-71 dBm
RSRP0	-97 dBm
RSRP1	-128 dBm
RSRQ	-5 dB



5.6.2.3 5.2.3.3 Manual Connect Mobile Network

To set the mobile network manual connect to the internet, perform the following steps:

- 1. Choose Network > LTE Settings;
- 2. In the **Setting** area, set the connect method as **Manual**, when the LTE network is ready, you can set the CPE connect to the LTE network or disconnect from the LTE network. As shown in Figure 5-9.

LTE Settings	
Settings	
Status	Disconnected
Connect Method	Manual 🔻
	Connect

Status

DL MCS	0
UL MCS	0
DL Frequency	2624.6 MHz
UL Frequency	2624.6 MHz
Bandwidth	20 MHz
RSSI	-53 dBm
RSRP0	-93 dBm
RSRP1	-85 dBm
RSRQ	-15 dB
SINR	0 dB
TX Power	0 dBm
PCI	20
CINR0	-6.7 dB
CINR1	4.6 dB
Cell ID	193
MCC	460
MNC	00

Figure 5-9

5.2.4 Scan Mode

This function is used to configure UE mode of scan network. The default scan mode is full band. To set the LTE network scan mode, perform the following steps:

- 1. choose Network>Scan mode;
- 2. If select **Bandlock**, UE will only connect to the checked bands. Others will not be scanned.
- 3. Click Submit. As shown in Figure 5-10.

Scan Mode	Band Lock
Band Lock	
Band Select	 Band 2 Band 4 Band 5 Band 12 Band 13 Band 14 Band 17
	 Band 25 Band 26 Band 38 Band 41 Band 42 Band 43 Band 48 Band 53 Band 66
	-



5.6.2.4 5.2.4.1 Setting EARFCN

To set the frequency, perform the following steps:

- 1 Choose Network>Scan Mode.
- 2 In the Scan Mode area, choose EARFCN Lock.
- 3 In the **EARFCN Lock** area, you can set an **EARFCN**, then click **Add** to add it to the EARFCN lock list.
- 4 Click Submit. As shown in Figure 5-11.

2100F12 User Manual

Settings				
Scan Mode	EARFCN Lock	•		
EARFCN Lock				
EARFCN	44500	• Add		
EARFCN Lock List	(Max Limit :5)			
		EARFCN	Operation	
Index				
Index 1		44500	Delete	



5.6.2.5 5.2.4.2 Setting PCI LOCK

To set the PCI lock perform the following steps:

- 1. Choose Network>Scan Mode.
- 2. In the Scan Mode area, choose PCI Lock.
- 3. In the **PCI Lock** area, you can set **PCI** of the cell, then click **Add** to add it to the PCI lock list.
- 4. Click **Submit**. As shown in Figure 5-12.

can Mode						
Settings						
Scan Mode	PCI Lock	~				
PCI Lock						
PCI		* Add				
PCI Lock List (MAX'5)					
i of Look Liet (WPVA.J /					
Index	MPA.37		PCI	Operation		
Index	WPA.3 /		PCI	Operation	Submit	Cancel
Index Nearby Cell List	тток		PCI	Operation	Submit	Cancel
Index Nearby Cell List			PCI	Operation	Submit Refresh eNB List	Cancel



5.2.5 APN Management

To set and manage APN, perform the following steps:

- 1. Choose Network>APN Management.
- 2. In the APN Management area, you can set the APN.
- 3. Choose an **APN number** which you want to set, there are 4 APNs selected.

- 4. In the **APN Setting** area you can set the APN parameters, such as enable or disable the apn, apn name, profile name.
- 5. Set the authentication type (chap or pap or none) and the username, password of it.
- 6. Set the PDN type: IPv4 or IPv6 or IPv4/v6 dual stack.
- 7. Click **Submit.** As shown in Figure 5-13.

If you want set an APN as **default gateway**, you should check that is enabled. And we can also set the APN apply to SNMP or TR069.

Device Information			
	APN Management		
WAN Settings			
LTE Settings	APN Selection		
Scan Mode	A DM Mumhor	1222	
APN Management	APN Number	# 1	()
PIN Management	APN Settings		
Dual SIM	- Sinking	in Frankis	
SIM Lock	Enable	Enable	
LAN Settings	Profile Name	APN1	
DMZ Settings	APN Name	ADMA	
Static Route	24 34 Hanke	Perior	
Ethernet	Authentication Type	NONE	•
ç WI-FI	PDN Type	IPv4	
🗸 Firewall			
🗟 VPN	Default Gateway	🗑 Enable	
₿IPv6	Apply To	I TR069	
*		SNMP	

Figure 5-13

5.2.6 PIN Management

To manage the PIN, you can perform the following operations on the PIN Management page:

- > Enable or disable the PIN verification.
- > Verify the PIN.
- Change the PIN.
- Set automatic verification of the PIN. As shown in Figure 5-14

Overview Status	Update Settings
Device Information	
Network	PIN Management
WAN Settings	
LTE Settings	
Scan Mode	The PIN lock of the USIM card protects the router against unauthorized accesses to the Internet. You can activate, modify, or deactivate the PIN.
APN Management	Note: The router cannot provide Internet services when the USIM card is not inserted or the PIN ventication failed
PIN Management	
Dual SIM	
SIM Lock	PIN Management
LAN Settings	USIM Card Status USIM Normal
DMZ Settings	
Static Route	
]]Ethernet	PIN V
₽WI-FI	Remaining Attempts 3
] Firewall	
VPN	Submit Cancel

Figure 5-14

5.6.2.6 5.2.6.1 Viewing the Status of the USIM Card

To view the status of the USIM card, perform the following steps:

- 1 Choose Network >PIN Management.
- 2 View the status of the USIM card in the USIM card status field.

5.6.2.7 5.2.6.2 Enabling PIN Verification

To enable PIN verification, perform the following steps:

- 1 Choose Network >PIN Management.
- 2 Set **PIN verification** to **Enable**.
- 3 Enter the PIN (4 to 8 digits) in the **Enter PIN** box.
- 4 Click Submit.

5.6.2.8 5.2.6.3 Disabling PIN Verification

To disable PIN verification, perform the following steps:

- 1 Choose Network >PIN Management.
- 2 Set **PIN verification** to **Disable**.
- 3 Enter the PIN (4 to 8 digits) in the Enter PIN box.
- 4 Click Submit.

5.6.2.9 5.2.6.4 Verifying the PIN

If PIN verification is enabled but the PIN is not verified, the verification is required. To verify the PIN, perform the following steps:

- 1 Choose Network >PIN Management.
- 2 Enter the PIN (4 to 8 digits) in the **PIN** box.
- 3 Click Submit.

5.6.2.10 5.2.6.5 Changing the PIN

The PIN can be changed only when PIN verification is enabled and the PIN is verified. To change the PIN, perform the following steps:

- 1 Choose **Network>PIN Management**.
- 2 Set PIN verification to **Enable**.
- 3 Set Change PIN to Enable.
- 4 Enter the current PIN (4 to 8 digits) in the **PIN** box.
- 5 Enter a new PIN (4 to 8 digits) in the **New PIN** box.
- 6 Repeat the new PIN in the **Confirm PIN** box.
- 7 Click Submit.

5.6.2.11 5.2.6.6 Setting Automatic Verification of the PIN

You can enable or disable automatic verification of the PIN. If automatic verification is enabled, the CPE automatically verifies the PIN after restarting. This function can be enabled only when PIN verification is enabled and the PIN is verified.

- 1 To enable automatic verification of the PIN, perform the following steps:
- 2 Choose **Network > PIN Management**.
- 3 Set Pin verification to Enable.
- 4 Set **Remember my PIN** to Enable.
- 5 Click Submit.

5.6.2.12 5.2.6.7 Verifying the PUK

If PIN verification is enabled and the PIN fails to be verified for three consecutive times, the PIN will be locked. In this case, you need to verify the PUK and change the PIN to unlock it.

To verify the PUK, perform the following steps:

- 1. Choose Network> PIN Management.
- 2. Enter the PUK in the **PUK** box.
- 3. Enter a new PIN in the New **PIN** box.
- 4. Repeat the new PIN in the Confirm PIN box.
- 5. Click Submit.

5.2.7 SIM Lock

If you want to connect a specify network, and the CPE can't connect other network, you can set a SIM lock.

To set the SIM lock, perform the following steps:

- 1. Choose Network>SIM Lock.
- 2. Input the PLMN you want to lock in the **PLMN** box.
- 3. Click **add** to add the PLMN in the lock list.
- 4. Click **Submit**. As shown in Figure 5-15.

2100F12 User Manual

Overview Status	Update Settings		
Device Information			
Antwork	SIM Lock		
WAN Settings			
LTE Settings			
Scan Mode	To put the new configuration in	to effect, must click Submit button after Add List	
APN Management			
PIN Management	Callinga		
Dual SIM	Seungs		
SIM Lock	PLMN	•	Add
LAN Settings			
DMZ Settings	PLMN List (Max Li	mit :5)	
Static Route	Index	DI MN	Operation
Ethernet	muex	PLMN	operation
ବ ୍ WI-F I			
			Submit Cancel

Figure 5-15

5.2.8 LAN Setting

5.6.2.13 5.2.8.1 Setting LAN Host Parameters

By default, the IP address is 192.168.0.1 with a subnet mask of 255.255.255.0. You can change the host IP address to another individual IP address that is easy to remember. Make sure that IP address is unique on your network. If you change the IP address of the CPE, you need to access the web management page with the new IP address.

To change the IP address of the CPE, perform the following steps:

- 1. Choose Network>LAN Settings.
- 2. In the LAN Host Settings area, set IP address and subnet mask.
- 3. In the **DHCP Setting** area, set the DHCP server to **Enable**.
- 4. Click **Submit**. As shown in Figure 5-16.

Device Information
A Network
WAN Settings
LTE Settings
Scan Mode
APN Management
PIN Management
Dual SIM
SIM Lock
LAN Settings

192.168.0.1	*
255.255.255.0	*
Enable	
	192.168.0.1 255.255.255.0 ✓ Enable

Figure 5-16

5.6.2.14 5.2.8.2 Configuration the DHCP Server

DHCP enables individual clients to automatically obtain TCP/IP configuration when the server powers on. You can configure the CPE as a DHCP server or disable it. When configured as a DHCP server, the CPE automatically provides the TCP/IP configuration for the LAN clients that support DHCP client capabilities. If DHCP server services are disabled, you must have another DHCP server on your LAN, or each client must be manually configured.

To configure DHCP settings, perform the following steps:

- 1. Choose Network Setting > LAN Settings.
- 2. Set the DHCP server to Enable.
- 3. Set **Start IP** address.

This IP address must be different from the IP address set on the LAN Host Settings area, but they must be on the same network segment.

4. Set End IP address.

This IP address must be different from the IP address set on the LAN Host Settings area, but they must be on the same network segment.

5. Set Lease time.

Lease time can be set to 1 to 10,080 minutes. It is recommended to retain the default value.

6. Click **Submit**. As shown in Figure 5-17.

Device Information				
T. Network	LAN Settings			
WAN Settings				
LTE Settings	LAN Host Settings			
Scan Mode	IP Address	102 100 0		
APN Management	IF Address	192.108.0.1		
PIN Management	Subnet Mask	255 255 255 0	•	
Dual SIM	DUCD Pattings			
SIM Lock	DHCP Settings			
LAN Settings	DHCP Server	 Enable 		
DMZ Settings	Start IP Address	102 169 0 10		
Static Route	Start in Providess	132.100.0.10		
Ethernet	End IP Address	192.168.0.100	•	
≑WI-FI	Lease Time	720		
💭 Firewall				
C VPN				Submit Cancel

Figure 5-17

5.2.9 DMZ Settings

If the demilitarized zone (DMZ) is enabled, the packets sent from the WAN are directly sent to a specified IP address on the LAN before being discarded by the firewall.

To set DMZ, perform the following steps:

- 1. Choose Network > DMZ Settings.
- 2. Set DMZ to Enable.

- 3. (Optional) Set **ICMP Redirect** to **Enable**.
- 4. Set Host address.

This IP address must be different from the IP address set on the LAN Host Settings page, but they must be on the same network segment.

5. Click **Submit**. As shown in Figure 5-18.

Device Information			
I_Network	DMZ Settings		
WAN Settings			
LTE Settings	DMZ		
Scan Mode	01/7	The Emphasis	
APN Management	DMZ	 Enable 	
PIN Management	ICMP Redirect	Enable	
Dual SIM	Host Address	* D1 0 237 C07	
SIM Lock	1 lost Address	132 100.0.10	
LAN Settings			
DMZ Settings			Submit Cancel

Figure 5-18

5.2.10 Static Route

5.6.2.15 5.2.10.1 Add Static Route

To add a static route, perform the following steps:

- 1. Choose Network Setting>Static Route.
- 2. Click Add list.
- 3. Set the Dest IP address and Subnet mask.
- 4. Select an Interface from the drop-down list.
- 5. If you select LAN as the interface, you need set a Gateway.
- 6. Click **Submit.** As shown in Figure 5-19.

Device Information						
T_Network	Static Route					
WAN Settings						
LTE Settings	Static Route List	(Max Limit :10)				
Scan Mode						Add List
APN Management						OUD FIST
PIN Management	Index De	estination IP Subnet Mask	Interface	Gateway	Status	Operation
Dual SIM						
SIM Lock	Static Route Sett	inge				
LAN Settings	Citato Hoata Oct	u.Ma				
DMZ Settings	Destination IP	202.100.14.202				
Static Route	Subnet Mask	255 255 255 255				
Ethernet						
€ Wi-Fi	Interface	LAN	•			
🛛 Firewall	Gateway	192.168.01	•			
S VPN						
₿IPv6					Su	omit Gancel

Figure 5-19

5.6.2.16 5.2.10.2 Modify Static Route

To modify an access restriction rule, perform the following steps:

1. Choose Firewall>Static Route.

- 2. Choose the item to be modified, and click **Edit**.
- 3. Repeat steps 3 through 5 in the previous procedure.
- 4. Click Submit. As shown in Figure 5-20.

Device Information	1					
I. Network	Static Route					
WAN Settings						
LTE Settings	Static Route List	t (Max Limit :10)				
Scan Mode						Add Liet
APN Management						AND LIST
PIN Management	Index D	Destination IP Subnet Mask	Interface	Gateway	Status	Operation
Dual SIM						
SIM Lock	Static Route Set	Hinde				
LAN Settings	Sidde Noule Se	an Ba				
DMZ Settings	Destination IP	202.100.14.202				
Static Route	Subnet Mask	255 255 255 255				
Ethernet						
æWi-Fi	Interface	LAN	•			
🕽 Firewall	Gateway	192.168.01	•			
₿IPv6					Su	bmit Gancel



5.6.2.17 5.2.10.3 Delete Static Route

To delete a static route, perform the following steps:

- 1. Choose Firewall>Static Route.
- 2. Choose the item to be deleted, and click **Delete**.

5.3 Ethernet

5.3.1 Ethernet Settings

In this area, you can select the connection mode of Ethernet, and there are three modes that you could choose. They are Dynamic IP, Static IP and LAN Only. perform the following steps:

1.Choose Ethernet > Ethernet Settings;

2.Set Connection mode to Dynamic IP/Static IP/LAN Only.

3. Click Save. As shown in Figure 5-21.





Submit Cancel

5.3.2 Ethernet Status

In this area, you can view the status about the Ethernet. To view the Ethernet status, perform the following steps:

1.Choose **Ethernet > Ethernet Status**;

2.In the **Ethernet Status** area, view the information about Connection mode, Link Status, Connect Status, Online Time, IP Address, Subnet Mask, Default Gateway, Primary DNS and Secondary DNS (the figure below is about **Dynamic IP mode**). As shown in Figure 5-22.

Overview Status I	Jpdate Set	ttings		
Device Information				
- Network	Etherne	et Status		
Ethernet				
Ethernet Settings	Stat	us		
Ethernet Status	Conr	nection mode	I	Dynamic IP
奈 ₩i-Fi	Link	status	1	Disconnected
Parental Controls	Conr	nection status	1	Disconnected
Pirewall	Onlir	ie Time	(00d 02h 18min
🗳 VPN	IP Ac	Idress		
₩ volP	Subr	et Mask		
∰IPv6	Dafa			
- Svstem	Dera	uit Gateway		
	Prim	ary DNS server		-
	Seco	ndary DNS server		-



5.5 Parental Controls

5.5.1 Enabling Parental Controls

To enable Parental Controls, perform the following steps:

```
1. Choose Settings > Parental Controls.
```

- 2.Set Parental Controls to Enable.
- 3.Click Save. As shown in Figure 5-33.

2100F12 User Manual

```
    Parental Controls

    Parental Controls

    Bnable

    Enable
```

Figure 5-33

Submit

5.5.2 Disabling Parental Controls

To disable Parental Controls, perform the following steps:

1.Choose Se	ttings > Parental Controls.	
2.Set Paren	tal Controls to Disable.	
3.Click Save	e. As shown in Figure 5-34.	
Parental Controls		
Parental Contro	is Manager	
Enable	🖹 Enable	
		Submit

Figure 5-34

5.5.3 Adding Parental Controls list

To add a Parental Controls list, perform the following steps:

- 1. Choose Settings >Parental Controls.
- 2.Click Add list.
- 3.Set Access Restriction to Enable.
- 4.Set Access Restriction Name.
- 5.Set Device MAC address or IP address.
- 6.Set Weekdays and time.

Descripted Constrain Link (1999) 11

7.Set Access Restriction status

8.Click Save. As shown in Figure 5-35.

					Add List
Index	Name	Device	Weekdays	Time	Operation
Settings					
Name	tost				
Device	192.168.1.1] •			
Weekdays	Mon Tue Wed	Thu Fri Sat Sun			
Time	10	10 15	• 0	19 C	

Figure 5-35

5.6Firewall

5.6.1 Setting Firewall

This page describes how to set the firewall. If you enable or disable the firewall, you can modify the configuration.

To set the firewall, perform the following steps:

- 1. Choose Firewall>Firewall Setting.
- 2. Choose **Enable** or **Disable** to modify the configuration.
- 3. Click **Submit**. As shown in Figure 5-36.

Fir	ewall Settings				
	Settings				
	Firewall	Enable			
			1	Submit	Cancel



If you choose enable the firewall, you can modify the configuration about firewall, such as Mac filter, IP filter, URL filter and so on. If you choose disable, you can't modify any configurations about the firewall.

5.6.3 MAC Filtering

This page enables you to configure the MAC address filtering rules.

5.6.3.1 Enabling MAC Filter

To enable MAC address filter, perform the following steps:

- 1. Choose Firewall>MAC Filtering
- 2. Set MAC filtering to **Enable**.
- 3. Click **Submit**. As shown in Figure 5-37.

MAC Filtering

MAC Filtering Manager

*	Enable
۲	Allow
\bigcirc	Deny
	•



5.6.3.2 Disabling MAC Filter

To disable MAC address filter, perform the following steps:

- 1. Choose Firewall>MAC Filtering
- 2. Set MAC filtering to **Disable**.
- 3. Click **Submit**. As shown in Figure 5-38.

MAC Filtering

MAC Filtering Manager

MAC Filtering	Enable
Within The Rule To Allow/Deny	Allow
	Deny

Figure 5-38

5.6.3.3 Setting Allow access network within the rules

To set allow access network within the rules, perform the following steps:

- 1. Choose Firewall>MAC Filtering.
- 2. Set **Allow access network** within the rules.
- 3. Click **Submit**. As shown in Figure 5-39.

MAC Filtering



Figure 5-39

5.6.3.4 Setting Deny access network within the rules

To set deny access network within the rules, perform the following steps:

- 1. Choose Firewall>MAC Filtering.
- 2. Set **Deny access network** within the rules.
- 3. Click Submit. As shown in Figure 5-40.

MAC Filtering

MAC Filtering Manager	
MAC Filtering	Enable
Within The Rule To Allow/Deny	Allow
	Deny
Figure 5-40	
A C Filtoning mulo	

5.6.3.5 Adding MAC Filtering rule

To add a MAC filtering rule, perform the following steps:

- 1. Choose Firewall>MAC Filtering.
- 2. Click Add list.
- 3. Set MAC address.
- 4. Click **Submit**. As shown in Figure 5-41.

MAC Filtering List	(Max Limit :32)			
				Add List
Index	MAC Address		Operation	
Settings				
MAC Address	00:12:61:ae:c0:89	*		
			Submit	Cancel

Figure 5-41

5.6.3.6 Modifying MAC Filtering rule

To modify a MAC address rule, perform the following steps:

- 1. Choose Firewall>MAC Filtering.
- 2. Choose the rule to be modified, and click Edit.
- 3. Set MAC address.
- 4. Click **Submit**. As shown in Figure 5-42.

			Add List
Index	MAC Address	Operation	
1	00:12:61:AE:C0:89	Delete Edit	
Settings			
Settings		*	
Settings MAC Address		*	

5.6.3.7 Deleting MAC Filtering rule

To delete a MAC address filter rule, perform the following steps:

- 1. Choose Firewall>MAC Filtering.
- 2. Choose the rule to be deleted, and click **Delete**. As shown in Figure 5-43.

```
MAC Filtering List (Max Limit :32)
```

			Add List
Index	MAC Address	Operation	
1	00:12:61:AE:C0:89	Delete Edit	



5.6.4 IP Filtering

Data is filtered by IP address. This page enables you to configure the IP address filtering rules.

5.6.4.1 Enabling IP Filtering

To enable IP Filtering, perform the following steps:

- 1. Choose Firewall>IP Filtering.
- 2. Set IP Filtering Enable.
- 3. Click **Submit**. As shown in Figure 5-44.

IP Filtering Manager



Figure 5-44

5.6.4.2 Disabling IP Filtering

To disable IP Filtering, perform the following steps:

- 1. Choose Firewall>IP Filtering.
- 2. Set IP Filtering **Disable**.
- 3. Click **Submit**. As shown in Figure 5-45.

IP Filtering Manager

IP Filtering	Enable
Except The Rules To	Allow
Allow/Delly	Deny



5.6.4.3 Setting Allow access network outside the rules

To set allow access network, perform the following steps:

- 1. Choose Firewall>IP Filtering.
- 2. Set Allow access network outside the rules.
- 3. Click **Submit**. As shown in Figure 5-46.

IP Filtering Manager

IP Filtering	Enable
Except The Rules To	Allow
Allow/Derly	Deny

Figure 5-46

5.6.4.4 Setting Deny access network outside the rules

To set allow access network, perform the following steps:

- 1. Choose Firewall>IP Filtering.
- 2. Set Deny access network outside the rules.
- 3. Click Submit. As shown in Figure 5-47.

IP Filtering Manager

IP Filtering	Enable
Except The Rules To Allow/Denv	Allow
alou bony	Denv

Figure 5-47

5.6.4.5 Adding IP Filtering rule

Add an IP address filtering rule, perform the following steps:

- 1. Choose Firewall>IP Filtering.
- 2. Click Add list.
- 3. Set **Service**.
- 4. Set **Protocol**.
- 5. In the **Source IP Address Range** box, enter the source IP address or IP address segment to be filtered.
- 6. In the **Source port range** box, enter the source port or port segment to be filtered.
- 7. In the **Destination IP Address Range** box, enter the destination IP address or IP address segment to be filtered.
- 8. In the **Destination port Range** box, enter the destination port or port segment to be filtered.
- 9. In the **Status** box, choose a status the rule will be executed.
- 10. Click **Submit**. As shown in Figure 5-48.

IP Filtering List	(Max Limit :32)		
	Source	_	

Index	Protocol	Source	Source Port Range	Destinati on IP	Destinati on Port Range	Status	Operatio n
Settings							
Service			Custom	•			
Protocol			ALL	•			
Source IP			192.10.64.123				
Source Por	t Range						
Destination	IP						
Destination	Port Range						
Status			Allow	•			
						1 11	
					S		Jancel

Figure 5-48

5.6.4.6 Modifying IP Filtering rule

To modify an IP filtering rule, perform the following steps:

- 1. Choose Firewall > IP Filtering.
- 2. Choose the rule to be modified, and click **Edit**.
- 3. Repeat steps 3 through 9 in the previous procedure.
- 4. Click **Submit**. As shown in Figure 5-49.

IP Filtering List (Ma	ix Limit :32)				
					Add List
Index Protocol S	Source ource IP Port Range	Destinati on IP	Destinati on Port Range	Status	Operatio n
Settings					
Service	Custom	T			
Protocol	ALL	•			
Source IP	192.10.64.123				
Source Port Range					
Destination IP	100.10.64.123				
Destination Port Range					
Status	Allow	•			
			S	ubmit	Cancel



5.6.4.7 Deleting IP Filtering rule

To delete an IP address filtering rule, perform the following steps:

- 1. Choose Firewall > IP Filtering.
- 2. Choose the rule to be deleted, and click **Delete**. As shown in Figure 5-50.

I Throwing Liot (Max Limit .52 /

							Add List	
Index	Protocol	Source IP	Source Port Range	Destinati on IP	Destinati on Port Range	Status	Operatio	n
1	ALL	192.10.64.12 3	N/A	100.10.64.12 3	N/A	Allow	Delete Edit	t



5.6.5 URL Filtering

Data is filtered by uniform resource locator (URL). This page enables you to configure URL filtering rules.

5.6.5.1 Enabling URL Filtering

To enable URL Filtering, perform the following steps:

- 1. Choose Firewall>URL Filtering.
- 2. Set URL Filtering to Enable.
- 3. Click **Submit**. As shown in Figure 5-51.

UR	L Filtering	
	URL Filtering Manag	er
	URL Filtering	Enable
	Figure 5-5	1
5.6.5.2 Disabling U	RL Filtering	
 To disable URL Filtering Choose Firewall>UR Set URL Filtering to Click Submit. As sho 	, perform the following steps & Filtering. Disable. wn in Figure 5-52. & Filtering	ï
	URL Filtering Mana	ager
	URL Filtering	Enable
	Figure 5-5	2
5.6.5.3 Adding URL	Filtering list	
 To add an URL filtering I Choose Firewall>UR Click Add list. Set URL. Click Submit. As sho URL Filtering 	ist, perform the following sto a L Filtering . wn in Figure 5-53. g List (Max Limit :32)	eps:
		Add List
Index	URL	Operation
Settings		
URL	www.google.com	*



Submit Cancel

5.6.5.4 Modify URL Filtering list

To modify an URL filtering rule, perform the following steps:

- 1. Choose Firewall>URL Filtering.
- 2. Choose the rule to be modified, and click Edit.
- 3. Set **URL** address.
- 4. Click **Submit**. As shown in Figure 5-54.

URL Filtering List (Max	Limit :32)	
		Add List
Index	URL	Operation
1	www.google.com	Delete Edit



5.6.5.5 Deleting URL Filtering list

To delete an URL list, perform the following steps:

- 1. Choose Firewall>URL Filtering.
- 2. Choose the item to be deleted, and click **Delete**. As shown in Figure 5-55.

URL Filtering List (Max Limit :32)

			Add List
Index	URL	Operation	
1	www.google.com	Delete Edit	

Figure 5-55

5.6.6 Port Forwarding

When network address translation (NAT) is enabled on the CPE, only the IP address on the WAN side is open to the Internet. If a computer on the LAN is enabled to provide services for the Internet (for example, work as an FTP server), port forwarding is required so that all accesses to the external server port from the Internet are redirected to the server on the LAN.

5.6.6.1 Adding Port Forwarding rule

To add a port forwarding rule, perform the following steps:

- 1. Choose Firewall > Port Forwarding.
- 2. Click Add list.
- 3. Set Service.
- 4. Set **Protocol**.
- 5. Set Remote port range.



The port number ranges from 1 to 65535.

6. Set Local host.



This IP address must be different from the IP address that is set on the LAN Host Settings page, but they must be on the same network segment. -----

7. Set Local port.

The port number ranges from 1 to 65535.

8. Click **Submit**. As shown in Figure 5-56.

Port Forw	arding List (Max Limit :32)			
					Add Li
Index	Protocol	Remote Port Range	ocal Host	Local Port	Operatio
Settings					
Service		Custom	•		
Protocol		ТСР	•		
Protocol Remote Port	Range	TCP 2000	*		
Protocol Remote Port Local Host	Range	TCP 2000 192.168.0.1	*		
Protocol Remote Port Local Host Local Port	Range	TCP 2000 192 168 0.1 3000	× *		

5.6.6.2 Modifying Port Forwarding rule

To modify a port forwarding rule, perform the following steps:

- 1. Choose Firewall > Port Forwarding.
- 2. Choose the item to be modified, and click **Edit**.
- 3. Re-config the service, protocol, and ports.
- 4. Click **Submit**. As shown in Figure 5-57.

Port Forwarding

Port Forw	varding List (Max Limit :32)			
					Add List
Index	Protocol	Remote Port Range	Local Host	Local Port	Operation
1	TCP	2000	192.168.0.1	3000	Delete Edit
Settings					
Service		Custom	•		
Protocol		TCP	•		
Remote Por	t Range	2000	*		
Local Host		192.168.0.1	*		
Local Port		3000	*		
				Submit	Cancel

Figure 5-57

5.6.6.3 Deleting Port Forwarding rule

To delete a port forwarding rule, perform the following steps:

1. Choose Firewall > Port Forwarding.

2. Choose the item to be deleted, and click **Delete**. As shown in Figure 5-58.

Port Forwarding List (Max Limit :32)

					Add List
Index	Protocol	Remote Port Range	Local Host	Local Port	Operation
1	TCP	2000	192.168.0.1	3000	Delete Edit

Figure 5-58

5.6.7 Port Triggering

5.6.7.1 Enabling Port Triggering

To enable **Port Triggering**, perform the following steps: 1.Choose **Firewall> Port Triggering**. 2.Set **Port Triggering** to **Enable**. 3.Click **Submit**. As shown in Figure 5-59.

	Port T	riggering				
	Po	ort Triggering	g Manager			
	Po	rt Triggering		Enable		
		Fig	gure 5-59			
5.6.7.2 D	Disabling Port	Friggering				
To disable U 1.Choose Fi 2.Set Port 3.Click Sub r	URL Filtering, per irewall> Port Tri Triggering to Dis mit. As shown in F	form the followinggering. able. Figure 5-60.	ng steps:			
	For	nggenng				
	Р	ort Triggerin	g Manage	r		
	Po	ort Triggering		Enable		
		Fig	gure 5-60			
5.6.7.3 A	dding Port Tri	ggering				
To add an U 1.Choose Fi 2.Click Add 3.Set Trigge 4.Click Sub	JRL filtering list, irewall> Port Tri list. ered Port and Forv mit. As shown in H	perform the follo ggering. varded Port. ⁷ igure 5-61.	wing steps:			
Port Triggering List	(Max Limit :32)					Add List
Index	Triggered Port	Triggered Protocol	Forwarded Port	Forwarded Protocol	Operation	
Settings Tragered Port Tragered Protocol Forwarded Port Forwarded Protocol	00 * TCP • 100 * TCP •				Submi	Canoel

Figure 5-61

5.6.7.4 Edit Port Triggering

To modify an URL filtering rule, perform the following steps:

1.Choose Firewall> Port Triggering.

2. Choose the rule to be modified, and click Edit.

- 3. Set Triggered Port and Forwarded Port.
- 5. Click **Submit**. As shown in Figure 5-62.

Pont Triggering List (Max Limit 32)							
						Add List	
Index	Triggered Port	Triggered Protocol	Forwarded Port	Forwarded Protocol	Operation		
1	80	TCP	80	TCP	Damp Edt		

Figure 5-62

5.6.7.5 Deleting Port Triggering list

To delete an **Port Triggering** list, perform the following steps:

- 3. Choose Firewall> Port Triggering.
- 4. Choose the item to be deleted, and click **Delete**. As shown in Figure 5-63.

Port mggenng List	(.Max-Limit :32.)				Ada
Index	Triggered Port	Triggered Protocol	Forwarded Port	Forwarded Protocol	Operation
t	80	TCP	00	TOP	Datata Edit

Figure 5-63

5.6.8 Access Restriction

Access R	estriction L	ist (Max	Limit :32)			
						Add List
Index	Enable	Name	Device	Weekdays	Time	Operatio
Settings						
Enable		🕑 Ena	able			
Name		ABC		*		
Device		00:12:6	1:AE:C0:89	*		
Weekdays		Mon	Tue Wed	Thu Fri	Sat Sun	
Timo		0	• · 0 •	_ 23 •	59 🔻	

Figure 5-64

5.6.8.1 Add Access Restriction

To add an access restriction rule, perform the following steps:

- 1. Choose Security>Access Restriction.
- 2. Click Add list.
- 3. Set Access Restriction to Enable.
- 4. Set Access Restriction Name.
- 5. Set Device MAC address or IP address.
- 6. Set Weekdays and time.
- 7. Click Submit.

5.6.8.2 Modify Access Restriction

To modify a access restriction rule, perform the following steps:

- 1. Choose Security>Access Restriction.
- 2. Choose the item to be modified, and click **Edit**.
- 3. Repeat steps 4 through 6 in the previous procedure.
- 4. Click Submit.

5.6.8.3 Delete Access Restriction

To delete a access restriction rule, perform the following steps:

- 1. Choose Security>Access Restriction.
- 2. Choose the item to be deleted, and click **Delete**.

5.6.9 UPnP

On this page, you can enable or disable the Universal Plug and Play (UPnP) function.

To enable UPnP, perform the following steps:

- 1. Choose Firewall > UPnP.
- 2. Set UPnP to Enable.
- 3. Click **Submit**. As shown in Figure 5-65.

PnP				
Settings				
UPnP		Enable		
				Submit
Current U	IPnP Status			
Index	Description	Protocol	IP Address	External Port Internal Port
		Figur	e 5-65	

5.6.10DoS

On this page, you can enable or disable the Denial of service (DoS) function.

- 1. Choose Firewall > DoS.
- 2. Set **UPnP** to **Enable**.
- 3. Click **Submit**. As shown in Figure 5-66.

DoS

DoS Settings	
DoS	Enable Disable
Sync flood	Enable
Ping flood	Enable
TCP port scan	Enable
UDP port scan	Enable
	Submit Cancel

Figure 5-66

5.7 VPN

This function enables you to connect the virtual private network (VPN). To connect the VPN, perform the following steps:

- 1. Choose VPN.
- 2. In the VPN Settings area, enable VPN.
- 3. Select a protocol from **Protocol** drop-down list.
- 4. Enter **Username** and **Password**.
- 5. Click Submit.
- 6. You can view the status in **VPN Status** area. As shown in Figure 5-67.

Device Information			
Network	VPN Settings		
Ethernet	VPN		
Wi-Fi	Protocol	L2TP V	
Firewall		*	
VPN	VFIN Server	172.16.34.120	
IPv6	Username	TEST *	
System	Password	···· ~ *	
	Host Name	cpe_lac	
	Bear Device	APN1 V	
	Default Gateway	Enable	
	IPsec Enable	Enable	
	IPsec Password	~ *	
	VPN Status		
	Username	Local Address Remote Address Online Time	

Figure 5-67

5.8 IPv6

Internet Protocol version 6 (IPv6) is the most recent version of the Internet Protocol (IP). Every device on the Internet is assigned an unique IP address for identification and location definition.

5.8.1 Status

The status page shows IPv6 information. As shown in Figure 5-68.

Status

IPv6 Information	
IPv6 Status	Enable
WAN Connection Type	AutoConfiguration
IPv6 MGMT Global Address	
LAN Address	
IPv6 DATA Global Address	
IPv6 Link-Local Address	fe80::1
AutoConfiguration Type	SLAAC
Figu	re 5-68

5.8.2 IPv6 WAN Settings

In this page, user can enable or disable IPv6 function. Meanwhile, user can set WAN Connection Type and the type of DNS.As shown in Figure 5-69

IP۱	6 WAN Settings			
	WAN			
	IPv6 Enable	Enable		
	WAN Settings			
	WAN Connection Type	AutoConfiguration •		
	IPv6 MGMT Global Address			
	DNS From	DHCPv6		
	Bear Device	APN1 •		
			Outerait	Canad
		T ' T (0)	 Submit	Cancel
		Figure 5-69		

5.8.3 IPv6 LAN Settings

In this page, user can choose the Autoconfiguration Type. As shown in Figure 5-70.

IPv6 LAN Settings				
LAN Settings				
IPv6 Link-Local Address	fe80::1			
AutoConfiguration Type	SLAAC	•		
	SLAAC DHCPv6			
			Submit	Cancel

Figure 5-70

5.9 System

5.9.1 Maintenance

5.9.1.1 Reboot

This function enables you to restart the CPE. Settings take effect only after the CPE restarts. To restart the CPE, perform the following steps:

- 1. Choose **System>Maintenance**.
- 2. Click **Reboot**. As shown in Figure 5-71 The CPE then restarts.

Reboot

Click Reboot to reboot device

Reboot

Figure 5-71

5.9.1.2 Reset

This function enables you to restore the CPE to its default settings.

To restore the CPE, perform the following steps:

- 1. Choose System>Maintenance.
- 2. Click **Factory Reset.** As shown in Figure 5-72. The CPE is then restored to its default settings.

Factory Reset

Click Factory Reset to restore device to its factory settings

Factory Reset

Figure 5-72

5.9.1.3 Backup Configuration File

You can download the existing configuration file to back it up. To do so:

- 1. Choose System>Maintenance.
- 2. Click **Download** on the **Maintenance** page.
- 3. In the displayed dialog box, select the save path and name of the configuration file to be backed up.
- 4. Click **Save**. As shown in Figure 5-73.

The procedure for file downloading may vary with the browser you are using.

Backup Configuration File

To backup the current configuration file, click Download.

Download

Figure 5-73

5.9.1.4 Upload Configuration File

You can upload a backed up configuration file to restore the CPE. To do so:

- 1. Choose System>Maintenance.
- 2. Click Browse on the Maintenance page.

- 3. In the displayed dialog box, select the backed-up configuration file.
- 4. Click **Open**.
- 5. The dialog box chooses. In the box to be right of Configuration file, the save path and name of the backed-up configuration file are displayed.
- 6. Click **Upload**. As shown in Figure 5-74.

The CPE uploads the backed-up configuration file. The CPE then automatically restarts.

Restore Configuration File

To restore the configuration file, specify the path of the local configuration file, import the file, and click ${\bf Upload}$ to restore the configuration file
Configuration File Choose File No file chosen
Upload

Figure 5-74

5.9.1.5 CBSD

You can input SAS Server setting in CBSD page

- 1. Choose System>CBSD. Figure 5.74A
 - 2. Click Browse on the CBSD page.
 - 3. In the displayed dialog box, Input SAS User ID.
 - 4. In the displayed dialog box, Device FCC ID will show for SAS requirement.
 - 5. In the display dialog box, Select SAS Grant Renew Range Value Default is 50.
 - 6. In the display dialog box, Input your SAS URL
 - 7. In the Display **Save** option will save the setting and device will send registration request to SAS sever.

fair Home	പ്പോ Statistics		Advanced Settings
Device Information	CBSD		
Ethernet Wi-Fi Security Settings VPN VoIP	Registration Parameters User ID FCC ID Grant Renew Range (2) SAS URL CBSD Sensil Number	NA	
Maintenance CBSD	Status		Save Cancel
DDNS Date & Time TR069	Register Status	Un-Registered	Reflact 1011
SNMP lperf	Current Certificate Subject:	NA	
Diagnosis Syslog	Common Name(CN) Organization Name(O)		
Port Mirror WEB Settings	Organization Unit(OU) Serial Number		
Account	Issuer:		

Figure 5.74A

5.9.2 TR069

TR-069 is a standard for communication between CPEs and the auto-configuration server (ACS). If your service provider uses the TR069 automatic service provision function, the ACS automatically provides the CPE parameters. If you set the ACS parameters on both the CPE and ACS, the network parameters on the CPE are automatically set using the TR-069 function, and you do not need to set other parameters on the CPE.

To configure the CPE to implement the TR-069 function, perform the following steps:

- 1. Choose System>TR069.
- 2. Set acs URL source. There are two methods, such as URL and DHCP.
- 3. In the ACS URL box, enter the ACS URL address.
- 4. Enter ACS **user name** and **password** for the CPE authentication.
 - To use the CPE to access the ACS, you must provide a user name and password for authentication. The user name and the password must be the same as those defined on the ACS.
- 5. If you set **Periodic inform** to **Enable**, set **Periodic inform interval**.
- 6. Set connection request user name and password.
- 7. Click **Submit**. As shown in Figure 5-75.

TR069

Settings		
Enable TR069	Enable	
ACS URL Source	URL	•
ACS URL	http://192.168.0.10/acs	*
ACS Username	tr069	*
ACS Password	•••••	*
Enable Periodic Inform	Enable	
Periodic Inform Interval	3600	*
Connection Request Username	tr069	
Connection Request Password	••••• har	

Figure 5-75

5.9.3 SNMP

You can enable SNMP and set config SNMP trap.

The UE will actively report changes of some certain values to the SNMP server. As shown in Figure 5-76.

SNI	MP				
	Settings				
	SNMP Enable	Enable			
	SNMP Walk on LAN	Enable			
	Trap Enable	Enable			
	Trap Server		*		
	Port		*		
				Cubrait	Canaal
				Submit	Cancer

Figure 5-76

5.9.4 Date & Time

You can set the system time manually or synchronize it with the network. If you select **Sync from network**, the CPE regularly synchronizes the time with the specified Network Time Protocol (NTP) server. If you enable daylight saving time (DST), the CPE also adjusts the system time for DST.

To set the date and time, perform the following steps:

- 1. Choose System > Date & Time.
- 2. Select Set manually.
- 3. Set Local time or click Sync to automatically fill in the current local system time.
- 4. Click **Submit**. As shown in Figure 5-77.

Date & Time

Settings	
Current Time	2020-03-26 18:52:33
Set Manually	
Local Time	2020 / 03 / 26 / 18 / 52 / 18 (format:YYYY/MM/DD/HH/MM/SS,the value of year is between 2000 and 2030)
	Sync
	Figure 5-77

To synchronize the time with the network, perform the following steps:

- 1. Choose **System > Date & Time**.
- 2. Select Sync from network.
- 3. From the **Primary NTP server** drop-down list, select a server as the primary server for time synchronization.
- 4. From the **Secondary NTP server** drop-down list, select a server as the IP address of the secondary server for time synchronization.
- 5. If you don't want to use other NTP server, you need to enable **Optional ntp server**, and set a server IP address.
- 6. Set Time zone.
- 7. Click **Submit**. As shown in Figure 5-78.

Date & Time	
Settings	
Current Time	2020-03-26 18:53:43
Set Manually	
Sync from Network	
Primary NTP Server	pool.ntp.org
Secondary NTP Server	asia.pool.ntp.org
Optional NTP Server	
Time Zone	(GMT+08:00) Beijing, Chongqing, Hong Kong, Urumqi

Figure 5-78

To set DST, perform the following steps:

- 1. Choose System>Date&Time.
- 2. Set **DST** enable.
- 3. Set Start Time and End Time.

DST

4. Click **Submit**. As shown in Figure 5-79.

DST	Enable
Start Time	Mar V Second V Mon V (2020-03-09) at 2 o'clock
End Time	Nov 🔻 First 🔻 Sun 🔻 (2020-11-01) at 2 o'clock
Status	Not Running
	Figure 5-79

The CPE will automatically provide the DST time based on the time zone.

5.9.5 DDNS

Dynamic Domain Name Server (DDNS) service is used to map the user's dynamic IP address to a fixed DNS service.

To configure DDNS settings, perform the following steps:

- 1. Choose **System > DDNS**.
- 2. Set DDNS to Enable.
- 3. In Service provider, choose DynDNS.org or oray.com.
- 4. Enter **Domain name** and **Host name**. For example, if the domain name provided by your service provider is test.customtest.dyndns.org, enter customtest.dyndns.org as Domain name, and test as Host name.
- 5. Enter User name and Password.
- 6. Click Submit. As shown in Figure 5-80.

DDNS

DDNS (Dynamic Domain Name System) is a service that allows network clients to connect to the wireless router, even with a dynamic public IP address, through its registered domain name.

DDNS Enable Service Provider WWW.DYNDNS.ORG Domain * Domain * Username * Password * Refresh 0 Enable Wildcard Enable WAN IP and domain verification Enable	DDNS Settings			
Service ProviderWWW.DYNDNS.ORGDomain*Username*Password*Cefresh0Enable WildcardEnableWAN IP and domain verificationEnable	DDNS	Enable		
Domain*Username*Password*Refresh0Enable WildcardEnableWAN IP and domain verificationEnable	Service Provider	WWW.DYNDNS.ORG	•	
Username * Password * Refresh 0 Enable Wildcard Enable WAN IP and domain verification Enable	Domain	*		
Password * Refresh 0 Enable Wildcard Enable WAN IP and domain verification Enable	Username	×		
Refresh 0 * Enable Wildcard Enable * WAN IP and domain verification Enable *	Password	*		
Enable Wildcard Enable WAN IP and domain verification Enable	Refresh	*		
WAN IP and domain verification 📄 Enable	Enable Wildcard	Enable		
	WAN IP and domain verification	n 🔲 Enable		
Submit Cancel			Submit	Cancel

Figure 5-80

5.9.6 Iperf

Iperf is a network performance testing tool. You can test TCP and UDP bandwidth quality. It can test the maximum TCP bandwidth, with a variety of parameters and UDP characteristics. Bandwidth, delay jitter and packet loss can be given.

5.9.6.1 TCP

To set TCP, perform the following steps:

1.Choose System>Iperf.

2.Set Trap Server.

3.Set Server Port (1024~65535).

4.Set Management Port (1024~65535).

5.Set Measurement Time (10~86400).

6.Set Protocol, select TCP.

7.Click **Save** and wait for few minutes, the results will be shown in the Result area. As shown in Figure 5-81.

lperf		
Settings		
Server Address	10.0.4.98	•
Server Port	5001	
Management Port	5001	•
Measurement Time	30	
Protocol Type	TCP	•
		Slatt Stop
Result		
Status	Running	
Uplink Speed	-	
Downlink Speed	-	

Figure 5-81

5.9.6.2 UDP

To set UDP, perform the following steps:

1.Choose System>Iperf.

2.Set Trap Server.

3.Set Server Port (1024~65535).

4.Set Management Port (1024~65535).

5.Set Measurement Time (10~86400).

```
6.Set Protocol, select UDP.
```

7.Set Packet Length (1~1470).

8.Set Udp Bandwidth.

9.Click **Save** and wait for few minutes, the results will be shown in the Result area. As shown in Figure 5-82.

erf			
Settings			
Server Address	10.0.4.98	*	
Server Port	5001	•	
Management Port	5001	. •	
Measurement Time	30		
Protocol Type	UDP	· •	
Data Length	1024		
UDP Bandwidth	19M		
			Sint Sip
Result			
Status	Running		
Uplink Latency	-		
Downlink Latency			
Uplink Speed	-		
Downlink Speed	22		

Figure 5-82

5.9.7 Diagnosis

If the CPE is not functioning correctly, you can use the diagnosis tools on the **Diagnosis** page to preliminarily identify the problem so that actions can be taken to solve it.

5.9.7.1 Ping

If the CPE fails to access the Internet, run the ping command to preliminarily identify the problem. To do so:

- 1. Choose System>Diagnosis.
- 2. In the Method area, select **Ping**.
- 3. Enter the domain name in the Target IP or domain field, for example, <u>www.google.com</u>.
- 4. Set Packet size and Timeout.
- 5. Set Count.
- 6. Click **Ping**. As shown in Figure 5-83.

Wait until the ping command is executed. The execution results are displayed in the Results box.

Method				
Method of Diagnostics	Ping			
	TraceRoute			
Ping				
Target IP/Domain	www.baidu.com	*		
Packet Size	56	*		
Timeout	10	*		
Count	4	*		
			Ping	Ca
Result				
Result	Pass			
Details	PING www.baidu.com (112 64 bytes from 112.80.248.7 64 bytes from 112.80.248.7 64 bytes from 112.80.248.7 64 bytes from 112.80.248.7 	80.248.75): 56 data bytes 5: seq=0 ttl=54 time=163.447 ms 5: seq=1 ttl=54 time=51.388 ms 5: seq=2 ttl=54 time=51.469 ms 5: seq=3 ttl=54 time=59.464 ms tistics		

Figure 5-83

5.9.7.2 Traceroute

If the CPE fails to access the Internet, run the Traceroute command to preliminarily identify the problem. To do so:

- 1. Choose System>Diagnosis.
- 2. In the Method area, select **Traceroute**.
- 3. Enter the domain name in the Target IP or domain field. For example, <u>www.google.com</u>.
- 4. Set Maximum hops ad Timeout.
- 5. Click Traceroute. As shown in Figure 5-84

Wait until the traceroue command is executed. The execution results are displayed in the Results box.

gnostics		
Method		
Method of Diagnostics	Ping	
	TraceRoute	
Traceroute		
Target IP/Domain	www.baidu.com *	
Maximum Hops	30 *	
Timeout	10 *	
	Tracero	oute Cance
Result		
Result	Pass	
Details	traceroute to www.baidu.com (112.80.248.75), 30 hops max, 38 byte packets 1 192.168.23.50 (192.168.23.50) 758.544 ms 2 * 3 10.0.10.1 (10.0.10.1) 224.854 ms 4 58.246, 124.193 (58.246, 124.193) 50.321 ms 5 112.64.249.145 (112.64.249.145) 31.167 ms 6 139.226.203.122 (139.226.203.122) 44.152 ms 7 139.226.225.153 (139.226.203.122) 44.152 ms 8 219.158.97.106 (219.158.97.106) 198.055 ms	

Figure 5-84

5.9.8 Port Mirror

Port mirroring is used on a network switch to send a copy of network packets seen on one switch port. To do so:

- 1. Choose System>Port Mirror.
- 2. Enable Port Mirror.
- 3. Select the **WAN Interface** which you want a copy.
- 4. Type the **Monitor IP**, where the copy will send to.
- 5. Click **Submit**. As shown in Figure 5-85.

```
Port Mirror
```

Enable
WAN Interface APN1
Forward IP Address 192.168.1.120 *

Submit Cancel

Figure 5-85

5.9.9 Syslog

The syslog record user operations and key running events.

5.9.9.1 Local

To set the syslog to local, perform the following steps:

- 1. Choose System>Syslog.
- 2. In the **Setting** area, set the method to **Local**.
- 3. In the **Level** drop-down list, select a log level.
- 4. Click **Submit**. As shown in Figure 5-86.

Syslog			
Settings			
Method	Network		
	Local		
Level	INFO •		
			Submit Cancel
Local			
Keyword	SyS		
Pull Syslog	Pull		
Clear Syslog	Clear		
esult			
6 06-18-13 OpenViH usernolice 6 06-18-13 OpenViH usernolice 6 06-18-19 OpenViH usernolice 6 06-18-22 OpenViH usernolice 6 06-18-22 OpenViH usernolice 6 06-18-23 OpenViH usernolice 6 06-18-23 OpenViH usernolice 6 06-18-33 OpenViH usernolice 6 06-18-33 OpenViH usernolice 6 06-18-33 OpenViH usernolice 6 06-18-34 OpenViH usernolice 6 06-18-35 OpenViH usernolice 6 06-18-35 OpenViH usernolice 6 06-18-35 OpenViH usernolice 6 06-18-35 OpenViH usernolice	systag. Receive reply patispeed. 1-1 systag. Receiver reply patispeed.		

Figure 5-86

Viewing local syslog

To view the local syslog, perform the following steps:

- 1. In the **Keyword** box, set a keyword.
- 2. Click **Pull**, the result box will display.

5.9.9.2 Network

To set the syslog to network, perform the following steps:

- 1. Choose System>Syslog.
- 2. In the **Setting** area, set the method to **Network**.
- 3. In the Level drop-down list, select a log level.
- 4. In the Forward IP address box, set a IP address.
- 5. Click **Submit**. As shown in Figure 5-87.

The syslog will transmit to some client to display through network.

Syslog

Settings				
Method	Network			
	Local			
Network				
Forward IP Address	192,168.1.120	*		
			Submit	Cancel



5.9.10 WEB Setting

To configure the parameters of WEB, perform the following steps:

- 1. Choose System> WEB Setting.
- 2. Set **HTTP** enable. If you set HTTP disable, you will can't login the web management page with the HTTP protocol from WAN side.
- 3. Set **HTTP port**. If you want to change the login port, you can set a new port in the box, the default HTTP port is 80.
- 4. Set **HTTPS** enable. If you want to login the web management page with the HTTPS protocol from WAN side, you need to enable the HTTPS.
- 5. If you want to login the web management page form the **WAN**, you need to Enable **Allowing login from WAN**.
- 6. Set the **HTTPS port**.
- 7. Click **Submit**. As shown in Figure 5-88.

WEB Settings

Settings				
HTTP Enable	Enable			
HTTP Port	80	*		
HTTPs Enable	Enable			
Allow HTTPs Login from WAN	Enable			
Allow PING from WAN	Enable			
HTTPs Port	443	*		
Refresh Time	10	*		
Session Timeout	10	*		
Language	English •]		
			Submit	Cancol
			Submit	Cancer

Figure 5-88

5.9.11 Account

This function enables you to change the login password of the user. After the password changes, enter the new password the next time you login.

To change the password, perform the following steps:

- 1. Choose System>Account.
- 2. Select the **user name**, if you want to change the password of normal user, you need to set **Enable User** enable.
- 3. Enter the current password, set a new password, and confirm the new password.
- 4. New password and Confirm password must contain 5 to 15 characters.
- 5. Click **Submit**. As shown in Figure 5-89.

Account

nange Password			
Isername	superadmin •		
rrent Password	\rightarrow	*	
w Password	\sim	*	
nfirm Password	hours?	*	
			Submit

Figure 5-89

5.9.12 Logout

To logout the web management page, perform the following steps:

1. Choose **System** and click **Logout**

It will return to the login page.

FAQs

The POWER indicator does not turn on.

- > Make sure that the power cable is connected properly and the CPE is powered on.
- > Make sure that the power adapter is compatible with the CPE.

Fails to Log in to the web management page.

- Make sure that the CPE is started.
- Verify that the CPE is correctly connected to the computer through a network cable. If the problem persists, contact authorized local service suppliers.

The CPE fails to search for the wireless network.

- Check that the power adapter is connected properly.
- Check that the CPE is placed in an open area that is far away from obstructions, such as concrete or wooden walls.
- Check that the CPE is placed far away from household electrical appliances that generate strong electromagnetic field, such as microwave ovens, refrigerators, and satellite dishes.

If the problem persists, contact authorized local service suppliers.

The power adapter of the CPE is overheated.

- The CPE will be overheated after being used for a long time. Therefore, power off the CPE when you are not using it.
- > Check that the CPE is properly ventilated and shielded from direct sunlight.

The parameters are restored to default values.

- If the CPE powers off unexpectedly while being configured, the parameters may be restored to the default settings.
- After configuring the parameters, download the configuration file to quickly restore the CPE to the desired settings.

DISCLAIMER

ALL CONTENTS OF THIS MANUAL ARE PROVIDED "AS IS". EXCEPT AS REQUIRED BY APPLICABLE LAWS, NO WARRANTIES OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE MADE IN RELATION TO THE ACCURACY, RELIABILITY OR CONTENTS OF THIS MANUAL.

TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, IN NO EVENT SHALL BE LIABLE FOR ANY SPECIAL, INCIDENTAL, INDIRECT, OR CONSEQUENTIAL DAMAGES, OR LOSS OF PROFITS, BUSINESS, REVENUE, DATA, GOODWILL SAVINGS OR ANTICIPATED SAVINGS REGARDLESS OF WHETHER SUCH LOSSES ARE FORSEEABLE OR NOT.

THE MAXIMUM LIABILITY (THIS LIMITATION SHALL NOT APPLY TO LIABILITY FOR PERSONAL INJURY TO THE EXTENT APPLICABLE LAW PROHIBITS SUCH A LIMITATION) OF ARISING FROM THE USE OF THE PRODUCT DESCRIBED IN THIS MANUAL SHALL BE LIMITED TO THE AMOUNT PAID BY CUSTOMERS FOR THE PURCHASE OF THIS PRODUCT.

Safety Information

This section contains important information about the operation of your device. It also contains information about how to use the device safely. Read this information carefully before using your device.

Electronic device

Do not use your device if using the device is prohibited. Do not use the device if doing so causes danger or interference with other electronic devices.

Interference with medical equipment

Follow rules and regulations set forth by hospitals and health care facilities. Do not use your device where prohibited:

- Some wireless devices may affect the performance of hearing aids or pacemakers. Consult your service provider for more information.
- Pacemaker manufacturers recommend that a minimum distance of 15 cm be maintained between a device and a pacemaker to prevent potential interference with the pacemaker. If using a pacemaker, hold the device on the side opposite the pacemaker and do not carry the device in your front pocket.

Areas with flammables and explosives

• Do not use the device where flammables or explosives are stored (in a gas station, oil depot, or chemical plant, for example). Using your device in these environments increases the risk of explosion or fire. In addition, follow the instructions indicated in

text or symbols.

• Do not store or transport the device in containers with flammable liquids, gases, or explosives.

Operating environment

- Avoid dusty, damp, or dirty environments. Avoid magnetic fields. Using the device in these environments may result in circuit malfunctions.
- Before connecting and disconnecting cables, stop using the device and disconnect it from the power supply. Ensure that your hands are dry during operation.
- Place the device on a stable surface.
- Keep the device away from electronic appliances that generate strong magnetic or electric fields, such as a microwave oven or refrigerator.
- During thunderstorms, power off your device and remove all cables connected to it to protect against lightning strikes.
- Do not use your device during thunderstorms to protect your device against any danger caused by lightning.
- Ideal operating temperatures are 0°C to 40°C. Ideal storage temperatures are -20°C to +70°C. Extreme heat or cold may damage your device or accessories.
- Keep the device and accessories in a well-ventilated and cool area away from direct sunlight. Do not enclose or cover your device with towels or other objects. Do not place the device in a container with poor heat dissipation, such as a box or bag.
- To protect your device or accessories from fire or electrical shock hazards, avoid rain and moisture.
- Keep the device away from sources of heat and fire, such as a heater, microwave oven, stove, water heater, radiator, or candle.
- Do not place any object, such as a candle or a water container, on the device. If any foreign object or liquid enters the device, immediately stop using it, power it off, and remove all cables connected to it. Then, contact an authorized service center.
- Do not block device openings. Reserve a minimum of 10 cm around the device to dissipate heat.
- Stop using your device or applications for a while if the device is overheated. If skin is exposed to an overheated device for an extended period, low temperature burn symptoms, such as red spots and darker pigmentation, may occur.
- Do not touch the device's antenna. Otherwise, communication quality may be reduced.
- Do not allow children or pets to bite or suck the device or accessories. Doing so may result in damage or explosion.
- Observe local laws and regulations, and respect the privacy and legal rights of others.
- The device should be installed and operated with a minimum distance of 20 cm between the radiator and your body.
- Keep the device in a place with good reception. The distance between the device and other metal materials (such as metal brackets or metal doors and windows) should be greater than 25 cm and the distance between the device should be greater than 30 cm.

Child's safety

- Comply with all precautions with regard to child's safety. Letting children play with the device or its accessories may be dangerous. The device includes detachable parts that may present a choking hazard. Keep away from children.
- The device and its accessories are not intended for use by children. Children should only use the device with adult supervision.

Accessories

- Using an unapproved or incompatible power adapter, charger or battery may cause fire, explosion or other hazards.
- Choose only accessories approved for use with this model by the device manufacturer. The use of any other types of accessories may void the warranty, may violate local regulations and laws, and may be dangerous. Please contact your retailer for information about the availability of approved accessories in your area.

Power adapter safety

- The power plug is intended to serve as a disconnect device.
- For pluggable devices, the socket-outlet shall be installed near the devices and shall be easily accessible.
- Unplug the power adapter from electrical outlets and the device when not in use.
- Do not drop or cause an impact to the power adapter. If it is damaged, take it to an authorized service center for inspection.
- If the power cable is damaged (for example, the cord is exposed or broken), or the plug loosens, stop using it at once. Continued use may lead to electric shocks, short circuits, or fire.
- Do not touch the power cord with wet hands or pull the power cord to disconnect the power adapter.
- Do not touch the device or the power adapter with wet hands. Doing so may lead to short circuits, malfunctions, or electric shocks.
- If your power adapter has been exposed to water, other liquids, or excessive moisture, take it to an authorized service center for inspection.
- Ensure that the power adapter meets the requirements of Clause 2.5 in IEC60950-1/EN60950-1/UL60950-1 and has been tested and approved according to national or local standards.

Cleaning and maintenance

- During storage, transportation, and operation of the device, keep it dry and protect it from collision.
- Keep the device and accessories dry. Do not attempt to dry it with an external heat source, such as a microwave oven or hair dryer.
- Do not expose your device or accessories to extreme heat or cold. These environments may interfere with proper function and may lead to fire or explosion.
- Avoid collision, which may lead to device malfunctions, overheating, fire, or explosion.

- If the device is not going to be used for an extended period of time, power it off, and remove all cables connected to it.
- If anything unusual occurs (for example, if the device emits smoke or any unusual sound or smell), immediately stop using it, power it off, remove all cables connected to it, and contact an authorized service center.

• Do not trample, pull, or excessively bend any cable. Doing so may damage the cable, causing the device to malfunction.

- Before you clean or maintain the device, stop using it, stop all applications, and disconnect all cables connected to it.
- Do not use any chemical detergent, powder, or other chemical agents (such as alcohol and benzene) to clean the device or accessories. These substances may cause damage to parts or present a fire hazard. Use a clean, soft, and dry cloth to clean the device and accessories.
- Do not place magnetic stripe cards, such as credit cards and phone cards, near the device for extended periods of time. Otherwise the magnetic stripe cards may be damaged.
- Do not dismantle or remanufacture the device and its accessories. This voids the warranty and releases the manufacturer from liability for damage. In case of damage, contact an authorized service center for assistance or repair.

Emergency calls

The availability of emergency calls is subject to your cellular network quality, service provider policy, and local laws and regulations. Never rely solely on your device for critical communications like medical emergencies.